## PRODUCT SPECIFICATION SHEET



www.accobrands.com.au

Product Code: 2305824
Brand Code: DERWENT®

Description: DERWENT® WATERBRUSH PUSH BUTTON CHISEL

TIP

Category: ARTS AND CRAFT



## **Tagline**

Drawn to perfection

## **Catalogue Copy**

Assorted point and chisel tip waterbrushes for a range of strokes. Large water barrel with push button for easy to control water release. Ideal for use with watersoluble paints and pencils. Durable nylon fibre tip holds shape and point for continuous use.

## **Features and Benefits**

- Large chisel tip waterbrush perfect for versatile strokes and washes.
- Large water barrel with push button for easy to control water release.
- Ideal for use with watersoluble paints and pencils.
- Portable and convenient for indoor and outdoor use.
- Durable nylon fibre tip holds shape and point for continuous use and comes with a protective cap.
- Comfortable handling and leak proof.

Dimensions				
WXLXH()	0x0x0			
Gross Weight ()	0			
Product Barcode				
Unit of Measure				
Minimum Order Quantity	12			
Inner Carton Dimensions				
Inner Unit Quantity	0			
WXLXH()	0x0x0			
Gross Weight ()	0			
Inner Barcode				
Outer / Shipper Carton Dimensions				
Outer Carton Quantity	0			
WXLXH()	0x0x0			
Gross Weight ()	0			
Outer Carton Barcode				
Shipping Information				
Lowest Possible Unit				
General Product Information				
Variant	CHISEL TIP			
Layers/Pallet	8			
Cases/Layer	384			

NEW SOUTH WALES	VICTORIA		WESTERN AUSTRALIA	NEW ZEALAND
2 Coronation Avenue	718 Geelong Rd		23 Marriott Road	29 Pukekiwiriki Pl
Kings Park NSW 2148	Brooklyn VIC 3012		Jandakot WA 6164	Highbrook Business Park
T: 02 9695 2500	T: 03 8348 4800		T: 08 9456 0100	East Tamaki Auckland 2013
				T: 09 633 2288